





Dongguan Sunhans Technology Co.,Ltd.

Address:Room 1103,Building 8,Gemdale Wisdom Park, No.95,Jiaoping Road,Tangxia Town,Dongguan City, Guangdong Province,China 523718

⊕ Z C€R₀HS F© Made in China

5G eSIMMobile WiFi Hotspot
User Manual

Contents

About Mobile Router	.2
Getting to know your device	.3
About Key	.4
About LED	.5
How to use	. 6
How to Charging	. 18
Device management	. 19
1. How to login WEBUI	.19
2. How to check or modify	
the Wi-Fi SSID and password	. 19
3. How to add new APN name manually	. 20
4. How to set Physical SIM card mode	21
5. How to view and set up devices	
through the touch screen	22
FAQ	. 29
1. The device cannot power on	. 29
2. I cannot access the Internet	. 29
3. I cannot find mobile router's SSID	.29
4. I cannot connect mobile router through	
Wi-Fi	.30
5. I forgot the Wi-Fi SSID and password	.30
6. What can I do if my mobile router is not	
getting charged	.30
Safety Warning	.31

About Mobile Router

Thank you for choosing eSunFi SHFiEL62. Instantly switch between data plans with the built-in eSIM technology, it can help you to access the Internet anytime, anywhere. After the device is started, it can be used as a hot spot of Wi-Fi. Users can build their own network scenarios simply and conveniently. The device can support 32 Wi-Fi terminals and1 USB client to access and share the mobile Internetat the same time.

Getting to know your device



About Key

Power Button Function:

- 1.Main function to Power On and Off the device.
- 2.Long press for 2-3 seconds, will turn on/off the device.
- Short press to wake up and turn off screen display.

Reset Button Function:

- Long press for three seconds will restore the device's factory settings.
- 2. Shore press to reboot the device.

About LCD

- 1. Mobile signal strength
- 2. 4G/5G data icon
- 3. 5.8GHz WiFi indicator & connected device
- 4. 2.4GHz WiFi indicator & connected device
- 5. Battery level
- 6. Screen lock
- 7. Date and time



How to use

Use physical SIM card to access the internet:

- 1. Insert SIM card and power on.
- After power on, the device will try attaching network automatically.
- Connect client to mobile router (support Wi-Fi ,USB).

Use eSIM plans to access the internet

 Download the eSIM manager for scanning the QR code:

Andriod: download eSIM Manager in Google Play Store

iOs: download eSIM Manager in Apple Store


 Buy eSIM plan from iLocalMe, Ubigi, Linksgo, Keepgo, Roambuddy, YOHO Mobile or any other eSIM data providers.

Remark: When purchasing an eSIM data plan, it is important to note whether the purchased eSIM plan supports WiFi hotspot sharing.

3. How to download eSIM profile from Android smartphone

3.1 Enter the main page and Add the eSIM Mifi






3.2 Choose Bluetooth connection




< X Add device	
Select device	
Realtek 44:28:A3:00:08:5C	*
Realtek E8:88:3D:20:4D:F8	*
Add device	


3.3 Add device and enter into the device profile management page






3.4 After selecting Profile List and click on the Click on the + sign, scanning QR code and starting up download and activating Profile by pressing "Activate" button . (The provisioning and activate process can be configured separately if customer required)












3.5 Operation video reference website link: https://youtu.be/kz1fbFhyrE0

4. Switch eSIM profile












5. Disable eSIM profile










6. Delete eSIM profile







A. Connect through Wi-Fi

- Click view available wireless networks in your devices.
- Choose Wi-Fi name (SSID)
 Default SSID can be found on the LCD display of Mobile router.
- Input the password
 Default password can be found on the LCD display of Mobile router.



B. Connect through USB

- Connect Mobile router and computer with USB cable
- After a few seconds of automatic installation, your computer can share mobile router's network

How to Charging

- 1. Charging through Power adapter
- Charging through USB connected to computer or power bank


Note:

- Please use the 5V/2A power adapter to charge the device.
- The charging time of charging through computer or power bank maybe longer than charging through Power adapter.
- The charging temperature of the product is between -10 °C and 60 °C, please keep the device within this temperature rang when charging.

Device management


1. How to login WEBUI


You can manage your device by login the WebUI(192.168.100.1). The default password is "admin".



How to check or modify the Wi-Fi SSID and password

It can be modified on LAN settings-->2.4G WLAN setting-->5G WLAN setting





3. How to add new APN name manually? Enter Mobile network settings--> Connection settings, click New





After entering the **Profile Name** and **APN**, click **Apply**.

4. How to set the Physical SIM card mode? Enter Mobile network settings-->eSIM setting, Select Physical sim




Click Apply to make the settings take effect

5. How to view and set up devices through the touch screen?


Short press the power button, hold down the lock icon and drag it to the right to enter the menu page.






Profile Management

Under this menu, users can freely choose Auto Match or manually set APN.



Wi-Fi Connection

Under this menu, users can scan the QR code or manually connect to WiFi.





2.4G WI-FI QRcode





SSID&Password

5G

___ name:




ZW62_2E65B6E




password: 00000000

Data Count

Under this menu, users can choose to count traffic on a daily, weekly, or monthly basis.






About

Under this menu, users can view device basic information and WiFi SSID and password.



Connected Users

Under this menu, users can view the clients connected to SHFiEL62.



ECO Settings

Under this menu, users can set backlight, charge, automatic boot, and sleep settings.




Settings

Under this menu, users can set WPS, Reset, Language, Password, and Initial Setting Wizard settings.



Network Setting

Under this menu, users can set PIN, Ping reply, eSIM/Physical SIM mode, Network mode, and Roam settings.



FAQ

1. The device cannot power on

Please charging your device firstly, and make sure that the environment temperature is between -10 $^{\circ}$ C and 60 $^{\circ}$ C.

2. I cannot access the Internet

- Check whether the SIM card is inserted correctly(new eSIM plans been enabled) and has good signal strength on LCD screen.
- APN setting is correct or not according to the new eSIM plans.
- Check whether the clients are connected to the mobile router correctly, either via the correct SSID over Wi-Fi or via USB.
- Ensure your SIM card(eSIM plan) has adequate data balance available.
- If the problem still persists, please get in touch with your service provider.

3. I cannot find mobile router's SSID

- · Make sure that device is power on
- Short Press power key to wake up Wi-Fi (maybe the device went into sleep mode)
- If the issue still exist, please press reset button to restore the factory settings.

4. I cannot connect mobile router through Wi-Fi

- Make sure the SSID and password is correct (it's case sensitive)
- · Make sure you have not set MAC Filter.
- If the issue still exist, please press reset button to restore the factory settings.

5. I forgot the Wi-Fi SSID and password

Don't worry, you can press reset button to restore the factory settings, and the default SSID and password can be find on the back casing of mobile router.

What can I do if my mobile router is not getting charged

- Check whether the charger and USB cable are working properly. It is recommended to use the 5V/2A charger and USB cable.
- Check if the environment temperature is too high or low. Device only can be charged when temperature is between -10 ℃ and 60 ℃.

Safety Warning

- Please use the 5V/2A power adapter to power the device.
- When mobile router is working, don't place metal objects in the use range to avoid signal interference.
- Do not open and touch the inner area of your device as it may affect your device performance.
- Magnetic stripe cards(including credit cards, phone cards, bank passbooks, etc.) may be damaged by magnetic field.
- If don't use mobile router for a long time, please take out the battery.

